

## SAYRE AREA SCHOOL DISTRICT TECHNOLOGY TIPS

### SETTING UP HS GYM PROJECTION CART

#### Purpose

To understand the general setup for the HS Gym Media Cart.

#### Equipment

1. **DVD/Blu-Ray – Sound System Controller** – This box was purchased by the HS P/E. Please note that there are 5 speakers that are attached to this to make the sound.



2. This is a **Dell projector** – Service Tag: HCX6LJ1. Link to serial Information picture [here](#) (only the SASD Tech Department can access this link). This projector was given by Technology. A Kingston lock was attached to the projector and cart with the key number V80246; one key is inside of the Technology Key Box, and the other has been given to the HS Library (Audio/Visual Designee).





## Build

1. First we are going to place the projector, sound system/DVD player box with speakers, power strip, extension cord, and yellow video-cord all on the cart.
2. Plug the power strip cord into the power source installed on the cart. This will give us the ability to use the longer-power cord from the cart itself.



3. Place the projector on the top portion of the cart



4. Please install the power cord for the projector from the back of the projector to the power strip.

5. Place the DVD/Sound System device on top of the cart similar to seen below:



6. Plug the power cord from the DVD player box into the power-strip.
7. Install the Yellow-video cable from the **Video Out** on the DVD player, to the **Video In** on the Projector.



Video Out



Video In

8. Next we are going to setup and connect all of the speakers to the appropriate connectors on the back of the DVD player/sound system box (**Please note the color coding**):



After we have setup all of the speaker wires appropriately, we have all of the equipment physically setup up.

**Proceed to the next document about how to turn on and use the equipment.**

[Using HS Gym Project Cart](#)

T:\HS Gym\Procedures\Using HS Gym Project Cart.docx

## Remotes

Please also note that we have two different remotes for use with this system:

1. Projector Remote:

This will be used to power on the projector, etc.:



2. DVD/Surround Sound System Remote:

This will be used to control the play/stop of media. This will also control different functions

such as volume control, etc.

