

SAYRE AREA SCHOOL DISTRICT TECHNOLOGY TIPS

APC UPS DESKTOP BASICS

Purpose

This handout is to briefly instruct how SASD APC UPS devices work with SASD Desktop PCs.

Hook Up

This handout is to briefly instruct how SASD APC UPS devices work with SASD Desktop PCs.

Key Point: Only have the PC system unit and the monitors hooked up to the APC UPS. This will allow the APC UPS to work properly when the power goes out.



Operation

Very easy to operate:

1. The APC UPS unit works automatically, when the power goes out, your PC and Monitors will be powered by the APC UPS battery.
2. This unit has enough battery to run for approximately 30 to 70 minutes (depending on the

- load).
3. During this time, the APC UPS unit will beep to alert you that the power from your outlet went out.
 4. Once the power is restored, the beeping will stop.

Indicator Lights:

GREEN – unit is working properly

RED – unit needs its battery replaced

Indicator Sounds:

ON BATTERY:

Beep 4 times every 30 seconds – unit is running on battery power (outlet power is off) – which means your PC and Monitor is being powered by battery.

Low Battery Warning:

Beep every ½ second. UPS is supplying battery power to the load connected to the Battery outlets and the battery is near exhaustion.

Constant Tone:

Battery is in need of charging or is needing replacement.