

SAYRE AREA SCHOOL DISTRICT TECHNOLOGY TIPS

INTRODUCTION TO THE NUMONICS TABLET MONITOR AND THE MULTIMEDIA PEN (PI-1900)

Purpose


An introduction to the Numonics Tablet Monitor

Monitor




- **Power Button** – Turn the Monitor On and Off
- **Touch Screen** – The pen manipulates actions on screen
- **Adjustable Stand** – Change angle of the monitor

Multimedia Pen Overview



- **Power Button** – Turn the Monitor On and Off
- **Left-Click** – The pen manipulates actions on screen
- **Right-Click** – Change angle of the monitor
- **Left-Double Click** – Like a mouse
- **Multimedia Pen Holder** – Holds the tablet pen

Using the Multimedia Pen




To turn the multimedia pen *ON* press the **Power Button In**.

The multimedia pen can be used as a mouse.

Clicking - Press the pen tip against the monitor and then release it.

(On default settings the pen tip acts like clicking the left mouse button.)





Double-Clicking - Press the pen tip against the monitor and release it *twice*.

Right-Clicking – Hold the pen tip *near* (1/4 Inch), but not on the monitor and press the side button of the pen.





To turn the multimedia pen *OFF* press the **Power Button Out**.

(Battery life can be prolonged by turning the multimedia pen OFF when not in use)